





QUICK START GUIDE

miniG SUB 3

PORTABLE RECHARGEABLE SUBWOOFER




1. UNPACKING - WHAT IS INSIDE THE PACKAGING




2. BLUETOOTH MODE

Connect via Bluetooth to your Minirig 3 or Minirig Mini, then plug your cables into the Subwoofer to turn it on.




3. CABLE MODE

Connect a cable from your device to the Minirig 3 or Minirig Mini and then from the Minirig to the Subwoofer.




4. POWER ON / OFF

Once powered with the cable you can press and hold the button for 2 seconds to turn on / off.




5. GAIN SETTINGS

You can toggle between low and high gain by pressing the LED button.



6. GAIN SETTINGS

To change the gain (volume) press and release button once.





Follow us for monthly mixes and giveaways.



For the full instruction manual download the User's Guide at:

WWW.MINIRIGS.CO.UK/SUPPORT