





MINI 19

PORTABLE RECHARGEABLE SUBWOOFER


QUICK START GUIDE MRS 2

1. UNPACKING - WHAT IS INSIDE THE PACKAGING




2. BLUETOOTH MODE

Connect via Bluetooth to your Minirig 2 or Minirig Mini, then plug your cables into the Subwoofer to turn it on.




3. CABLE MODE

Connect a cable from your device to the Minirig 2 or Minirig Mini and then from the Minirig to the Subwoofer.




4. POWER ON / OFF

Once powered with the cable you can press and hold the button for 2 seconds to turn on / off




5. GAIN SETTINGS



6. GAIN SETTINGS

To change the gain (volume) press and release button once





For the full instruction manual
download the User's Guide at:

WWW.MINIRIGS.CO.UK/SUPPORT